


1	2
3	4
5	6
7	8
9	10
11	12
13	14
15	16
17	18
19	20
21	22
23	24
25	26
27	28
29	30
31	32
33	34
35	36
37	38
39	40
41	42
43	44
45	46
47	48
49	50
51	52
53	54
55	56
57	58
59	60

1	2
3	4
5	6
7	8
9	10
11	12
13	14
15	16
17	17

1	PWRKEY	51	GPIO10/KBC0
2	PWRKEY_OUT	50	GPIO9/KBC1
3	DTR	49	GPIO8/KBC2
4	RI	48	GPIO7/KBC3
5	DCD	47	GPIO6/KBC4
6	DCD	46	GND
7	DSR	45	GND
8	CTS	44	GPIO5/KBR0
9	RTS	43	GPIO4/KBR1
10	TXD	42	GPIO3/KBR2
11	RXD	41	GPIO2/KBR3
12	DISP_CLK	40	GPIO1/KBR4
13	DISP_DATA	39	GND
14	DISP_D/C	38	SCL
15	DISP_CS	37	SDA
16	VDD_EXT	36	PWM2
17	NRESET	35	PWM1
18	GND		
19	MIC_P		
20	MIC_N		
21	SPK_P		
22	SPK_N		
23	LINEIN_R		
24	LINEIN_L		
25	ADC		
26	VRTC		
27	DBG_TX		
28	DBG_RX		
29	GND		
30	SIM_VDD		
31	SIM_DATA		
32	SIM_CLK		
33	SIM_RST		
34	SIM_PRESENCE		
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57			
58			
59			
60			
61			
62			
63			
64			
65			
66			
67			
68			



<b>www.tme.vn</b>		
Title SIM900-HEADER		
Size A	Document Number <Doc>	Rev <RevCo>
Date:	Thursday, January 12, 2012	Sheet 1 of 1